



Attach OXO screen jamb (↔) to XX adaptor (↔) by snapping it on. Secure screen jamb with three #7 x 7/16" self drilling screws, one at each end and one the same height as the door latches.